

***It is highly recommended to charge for at least 5 hours before first use.**

GP2100 - PowerSkin User manual

1.4 in 1

- Linear vibration for Game : 2 linear motors
- External battery for power : 2,050mAh
- Built-in stereo speaker for sound : 2W
- Game grip for ultimate control : Game cradle



2.What's in box

- GP2100 - PowerSkin
- USB sync. & charge cable
- User manual

3.Specification

- Product Name : GP2100 - PowerSkin Cradle
- Compatibility : iPhone 4 / 3GS / 3G
- Main Function
 - : iPhone auxiliary battery pack : 2,050mAh
 - : Built-in speaker : 2W digital stereo speaker
 - : Pulsating vibration : Linear vibration in 4 levels
- color : Black / White
- Size : 159 x 69 x 19 mm
- Weight : Approx. 118g
- Charge time : Approx. 4 - 6 hour
- Machine usable operation time for other use
 - : Calling time : Approx. 10 hour
 - : Internet with Mobile Net : Approx. 5 hour
 - : WiFi : Approx. 6 hour
 - : Music Play : Approx. 50 hour
 - : Movie and Game : Approx. 10 hour
- Speaker output: 2W (1W X2)
- Vibration motor : Linear AC motor 2 EA

***Disable Phone vibrate (Silent) mode before using.**
***You can see all status of GP2100 - PowerSkin by LED color.**



***For charging iPhone, please connect iPhone to GP2100 - PowerSkin**

***GP2100 - PowerSkin do not support Headset for call**

1.Charging GP2100 - PowerSkin

- Connect GP2100 - PowerSkin to PC or Apple's AC adaptor with the supplied USB cable.

2.LED color during charge and operation

- LED Red color: battery is charging
- LED Red & Blue color: charged approx. 70%
- LED Blue color: fully charged
- LED Blue color: Battery remaining more than 40%
- LED Red & Blue color: Battery remaining less than 40%
- Blinking LED Red color: Battery remaining less than 5%
- When remaining battery goes below pre-set limit, all the LED and power will be automatically turned off.

3.Earphone (headphone) connected to GP2100 - PowerSkin

- When earphones connects, speakers are turned off.
- When earphone disconnects, speakers are turned on.

4.Mute & GP2100 - PowerSkin Power off / on

- When you press shortly Mute button . Mute turns On or Off.
- When you press Mute button for approx. 3 seconds, GP2100 - PowerSkin power turns On or Off.

5.Volume Up / Down (20 levels)

- Press Up (+) key to increase volume
- Press Down (-) key to decrease volume

***Because of iPhone authentication issues, a warning message can come out on**
***If you have a problem with your GP2100 - PowerSkin, Press "Reset hole" using the tweezers**

6.To adjust the vibration level

- There are 4 levels of vibrations
- For changing vibration level, press vibration button with short interval.
- Using the buttons, you can choose your favorite vibration level according to game played.
- LED color is displayed with "Blue", "Blue and Red", "Red" and "Red blinking" for 1 second, respectively.
 - : LED is Red color blinking: Vibration Off
 - : LED is Blue color: Soft vibration,
 - : LED is Blue and Red Color: Medium vibration,
 - : LED is Red Color: Strong vibration
- Once vibration level selection is done, LED color indicates battery remaining status

7.Turn Off iPhone Display

iPhone's screen will be turned on/off when you press iPhone Display button.

Warranty covers your GP2100 - PowerSkin for one year (date of purchase).

GP2100 - PowerSkin excludes coverage for damage resulting from accident, disassembly, unauthorized service and unauthorized modifications.



www.power-skin.com



www.power-skin.com

©2011 XPAL Power Corporation. All rights reserved. The XPAL Power logo, charge on! logo, octopus graphic, tentacle graphic, XPAL Power, and PowerSkin are trademarks and/or service marks of XPAL Power and TennRich International Corporation. All other trademarks, brand names or product names are the property of their respective owners and are not affiliated with XPAL Power and or TennRich International Corporation.



PowerSkin®

U_1_GP2100_EN_1.1

版次 : U_1_GP2100_EN_1.1
 材質 : 風琴折 (請使用環保材質)
 尺寸 : 1:1